

## B and T Lymphocyte Quant by Flow

Order Name: **B T Lymph Qnt**  
Test Number: 5582618  
Revision Date: 05/24/2023

TEST NAME	METHODOLOGY	LOINC CODE
B and T Lymphocyte Quant by Flow	Flow cytometry	

### SPECIMEN REQUIREMENTS

Specimen	Specimen Volume (min)	Specimen Type	Specimen Container	Transport Environment
Preferred	<b>5 mL each (3 mL each)</b>	<b>Whole Blood</b>	<b>EDTA (Lavender) and ACD Sol A/B (Yellow Top)</b>	<b>Room Temperature</b>

**Instructions** Collect Whole blood in **Both ACD Solution A or B (Yellow Top)** and **EDTA (Lavender Top)**.

Keep whole blood, do not centrifuge or refrigerate.

**Deliver to the laboratory ASAP - Same Day as Collection!**

**Stability:** Room Temperature, Yellow-top (ACD-A) or (ACD-B) tube: 2 days Lavender-top (EDTA) tube: 1 day

**Collect Monday through Wednesday only. Specimens must be received at Labcorp Oklahoma Inc. by Wednesday afternoon or collect on Monday.**

### GENERAL INFORMATION

Testing Schedule	Testing schedule may vary.
Expected TAT	3-5 days,
Clinical Use	This test is also known as: Lymphocyte Quant by Flow or Flow Abbreviated Immunophenotype Panel This is a semi-quantitative assay that measures both the relative and absolute numbers of B cells and T cells in the peripheral blood, which may be useful in the initial evaluation of patients with suspected immunodeficiency.
Performing Labcorp Test Code	096917
CPT Code(s)	86355; 86359; 86360
Lab Section	Reference Lab