

## Lymphocyte Absolute CD4 Count

Order Name: **T Helper**  
Test Number: 3654600  
Revision Date: 05/24/2023

TEST NAME	METHODOLOGY	LOINC CODE
Lymphocyte Absolute CD4 Count	Flow cytometry	

### SPECIMEN REQUIREMENTS

Specimen	Specimen Volume (min)	Specimen Type	Specimen Container	Transport Environment
Preferred	<b>5 mL each (3 mL each)</b>	<b>Whole Blood</b>	<b>EDTA (Lavender) and ACD Sol A/B (Yellow Top)</b>	<b>Room Temperature</b>

Instructions	<p>Collect Whole blood in <b>Both ACD Solution A or B (Yellow Top)</b> and <b>EDTA (Lavender Top)</b>. Keep whole blood, do not centrifuge or refrigerate. Deliver to the laboratory ASAP - Same Day as Collection! <b>Collect Monday through Wednesday only. Specimens must be received at Labcorp Oklahoma Inc. by Wednesday afternoon or collect on Monday.</b> Stability: Room Temperature: Yellow-top (ACD-A) or (ACD-B) tube: Lavender-top (EDTA) tube: 1 day</p>
--------------	---

### GENERAL INFORMATION

Testing Schedule	Testing schedule may vary.
Expected TAT	3-5 days
Clinical Use	Marker for level of immunocompetence. The T4 Lymphocytes reports out values for Lymphocyte Percent CD4 and Lymphocyte Absolute CD4
Performing Labcorp Test Code	505008
CPT Code(s)	86361
Lab Section	Reference Lab